



OPERATING INSTRUCTIONS

Be sure equipment is connected to properly grounded 120 volt power supply with 15 amp circuit.

Popping

1. Turn on two switches.
POWER and KETTLE.
2. Allow kettle to warm for approximately 5 minutes.
3. **PORTION PACKS:** Cut off top of plastic pack. Dump entire contents in kettle. Pull lid closed to prevent stray kernels. (Lid is held in place by magnet directly above the kettle.)
4. While corn is popping, keep front operator doors closed. Keep hopper door at "out" position to reduce fogging.
5. Allow corn to pop until popping ceases, usually when 3-4 seconds lapse between pops. **Immediately turn Kettle switch to off position to avoid burning of popcorn.** Then pour remaining popped corn from kettle by rotating handle clockwise 1/3 turn and pulling downward.
6. Repeat steps 1-5 for additional batches.
7. POWER or LIGHT switch may remain ON to display and heat popcorn.

KETTLE WILL BE HOT! Please be sure to avoid direct contact with the kettle during the popping process!